



Dell Optiplex GX620 Side Panel Disassembly

This guide will show you how to remove the side panel from a Dell Optiplex GX620.

Written By: Kristina



INTRODUCTION

To access all other parts, you must first remove the cover.

Step 1 — Side Panel



- With the computer standing upright, firmly pull on the tab at the back of the computer.
- When the side panel pops free, gently pull the panel away from the computer.
- ⓘ If you have trouble freeing the side panel from the case, you may need to pull the tab a bit harder.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 10:44:52 PM.